

TLM ROOM THERMOSTATS

TLM 2253 TLM 2628 TLM 2655
TLM 2660 TLM 2802

Thermostat Position: To be placed at a height of 1.52m(5ft) from floor.
Do not position on an outside wall, above a radiator, next to a door, or in direct sunlight.

For fixed wiring only
WARNING

This control must be earthed using the earth screw on the backplate. Disconnect mains supply before fitting unit to backplate, or removing cover. A switch having a contact separation of at least 3mm in all poles must be incorporated in the fixed wiring as a means of fully disconnecting the mains supply.

FIXING

- 1. A metal backplate is supplied for direct mounting to wall, or to a one gang conduit box. Conforming to BS4662:1970(1989). Fit directly to wall using screws and fixings, or screw directly onto conduit box.
- 2.Loosen screws top and bottom of thermostat, remove main cover, remove knob and swing terminal cover open.
- 3.Route wires through back of thermostat and offer thermostat up to backplate. Secure to backplate using the two captive screws.
- 4.Connect wires to thermostat in accordance with the relevant wiring diagram shown overleaf and to the current I.E.E. regulations.
- 5.Reposition terminal cover, replace knob and main cover. Secure by tightening the two retaining screws.
- 6.Remove protective film from knob and cover.
- 7.Before connecting to the mains supply ensure that an appropriate fuse is fitted to the circuit.

SETTING

- 1. To set the required temperature, turn the knob until the triangle on the knob disc aligns with the desired temperature on the scaleplate.
- In line with a policy of continuous product development, Survic Controls Ltd. Reserve the right to change the specification, design and materials of products without prior notice.

WARNING

The cover must not be removed unless the thermostat is isolated from the electrical supply
Interference with sealed parts renders guarantee void.

Installation leaflet LE0213/0005Issue 0 June 98

a	Load (resistive)
b	Shunt accelerator heater
c	Temperature set-back heater
d	Time switch contacts
e	Temperature set-back switch

TLM 2253 TLM 2628 220-240V ~	4 -13 A 	TLM 2253 13 - 16A TLM 2628 13 - 20A
TLM 2655 220-240V ~	4 -13 A 	13 -20A
TLM 2802 220-240V ~	4 -13 A 	13 - 20A