



PN322 Fitting Instructions

Fitting instructions

1. Prepare circular hole in floor 100mm (4") minimum, 150mm (6") maximum, 75mm (3") deep.
2. Push the decorative cover (1) onto the lower portion of the upright tube (2) and screw the locknut (3) on to the thread as far as it will go.
3. Screw the mounting flange (4) onto the upright tube.
4. Tighten the locknut (3) on to the mounting flange (4).
5. Screw the water feed pipes (5) into the base of the fitting. Follow the instructions on the pipes for correct installation.
6. Pass the feed pipes through the hole in the floor and screw the mounting flange (4) to the floor.
7. Push the decorative cover (1) onto the floor.
8. Apply petroleum jelly to the seal (6) and fit in top of upright tube (2)
9. Screw the collar (7) into the top of the tube (1), hand tightened only.
10. Remove the O ring (8) from the spout.
11. Fit the hose (9) to the outlet, and the handset (11) to the hose, ensuring sealing washers (10) are in place.
12. Connect the feed pipes to supply and check thoroughly for leaks