

AFTER CARE INSTRUCTIONS

Your fitting has been manufactured to a high quality finish therefore should be treated with care to preserve its visible appearance. All surface finishes will wear if not cleaned correctly, the recommended and safest way to clean your fitting is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All domestic cleaning products, including non-scratch cleaners, can damage the surface and appearance of your fitting.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

NOTE: The 5-year guarantee on the valve is invalidated if damaged by any waterborne debris.

In the interest of continuous product development we reserve the right to alter specifications as necessary.

PRODUCT CODE: RO DSM C

TELEPHONE HELPLINE : 0844 701 6273

Bristan Group Ltd
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK
A Masco Company

Web Site: www.bristan.com
Telephone: 0844 701 6274
Facsimile: 0844 701 6275
Email: enquire@bristan.com

BRISTAN

Rio Deck Sink Mixer

Fitting Instructions & Contents List

Please keep these instructions for future reference and request of replacement parts.

(F) RO DSM)

(Rev. D2)

(H)

For latest prices and delivery to your door visit MyTub Ltd 0845 303 8383 www.mytub.co.uk



WATER PRESSURE

This mixer is suitable for use at all supply pressures. However for optimum use both the hot and cold supplies should be reasonably balanced. If the fitting is installed at low pressure (tank fed), then the minimum distance from the outlet of the nozzle to the underside of the cold tank should be 2 metre to ensure adequate performance.

N.B. This mixer is supplied with a single check valve fitted to the hot inlet. To comply with Water Regulations a further check valve should be fitted to the cold supply. For further details contact your Local Water Authority.

INSTALLATION


1. Identify all components and check for completeness, particularly before arranging fitting.
2. Fit the spout (1) into the body (2), secure in place with grub screw ensuring the spout is able to rotate freely.
3. Fit the mixer to the sink, using the plinths with 'o' rings (3) above and backnuts (4) below, and connect the hot and cold water supplies.
4. Fully open both valves, letting them run for a few minutes to check all joints and connections for leaks.
5. See over the page for aftercare instructions.

MAINTENANCE

If the fitting begins to drip:

1. Turn off the water supply.
2. Remove cap (a) and indice (b), loosen handle screw (c) and lift off handle (d). Unscrew shroud (e).
3. Unscrew ceramic disc valve and carefully clean seating, rubber seal and ceramic disc.
4. Replace valve, shroud and handle then turn on the water supply.
5. Contact our helpline if problem persists.

INSTALLATION DIAGRAM



Please note:

In the unlikely event you find a part missing please contact our Customer Service Help line on 0844 701 6273 for immediate dispatch of part.