



AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your waste is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non-scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning; a 3 year guarantee covers these finishes. The new infinity finish carries a lifetime guarantee.

PRODUCT CODE: W BTH12 (*)

TELEPHONE HELP LINE! 0844 701 6273

Bristan Limited
Birch Coppice Business Park
Dordon
Tamworth
Staffordshire
B78 1SG
UK

Web site: www.bristan.com

Telephone: 0844 701 6274

Facsimile: 0844 701 6275

Email: enquire@bristan.com

FI W BTH12

(D2)

MZ

BRISTAN

Exposed Bath Waste

(W BTH12 C/G)

Fitting Instructions

Please keep these instructions for future reference

INSTALLATION

N.B. please quote the name and product code of your fitting should need to phone the help line. This will ensure a speedier service regarding any inquiries.

1. Identify all components and check for completeness.
2. Assemble waste as shown by sliding nuts (2) onto tube with washer (3) and rubber seal (4) inside each nut. Slide tube into waste body (14) and overflow elbow (5) and tighten nuts. The waste can be adjusted to fit bath by raising or lowering overflow elbow on tube.
3. The small foam washer (6) and the waste seal (13) go between the overflow elbow and the waste body, respectively, and the bath.
4. Screw the overflow face (7) to the overflow elbow. Screw the waste flange (11) to the waste body, making sure the large foam washer (12) is between flange and bath.
5. If not fitted, open the triangular hook on the plug chain and close into plug, then attach the other end of the chain to the overflow face.
6. Check all joints and connections for leaks.
7. See over the page for aftercare instructions.

COMPONENTS

- | | |
|----------------------|-----------------------|
| 1. Waste tube | 8. Screw |
| 2. Nut | 9. Chain assembly |
| 3. Washer | 10. Plug |
| 4. Rubber seal | 11. Waste flange |
| 5. Overflow elbow | 12. Large foam washer |
| 6. Small foam washer | 13. Waste seal |
| | 14. Waste body |

