

TS1500, TS1503, OPAC, DELUXE, MIXAGE, GRAPHITE

DIAGRAM 1




DIAGRAM 2




DIAGRAM 3





DIAGRAM 4



- TO DIS-ASSEMBLE CARTRIDGE
- REMOVE CARTRIDGE FROM VALVE BODY. AS PER DIAGRAM 1
- UNSCREW HALF CARTRIDGE (1) BY INSERTING A FLAT TOOL SUCH AS A FLAT FILE THROUGH THE HALF CARTRIDGE SLOTS AND A SPANNER OR VICE ON THE LARGE HEXAGON OF THE HEAD DRIVING ONE AGAINST THE OTHER (THE HALF CARTRIDGE IS A STANDARD RIGHT HAND THREAD). AS PER DIAGRAM 2
- REMOVE THE CIRCLIP (2) AND PUSH OUT THE SPINDLE ASSEMBLY. AS PER DIAGRAM 3
- UNSCREW THE SPINDLE (3) FROM THE SPINDLE HOUSING (LEFT HAND THREAD). AS PER DIAGRAM 4