

Extended Curved Bath Screen

Instruction Manual

CBC



Consumer Guarantee

Please make sure the purchaser/end user completes and returns the Guarantee card which is enclosed with this product. Failure to validate the Guarantee will mean only the 1 Year Statutory Guarantee will apply.

IMPORTANT

- 1 Please ensure the consumer guarantee card enclosed with this product is completed and returned; please ensure the end user retains this manual.
- 1 Please read these instructions carefully prior to attempting installation.
- 1 Unpack and handle the product with care to avoid damage to the product finish.
- 1 Check for hidden electrical cables and water pipes prior to commencing any drilling work.
- 1 Ensure the walls where the Bath Screen is to be fitted are vertical (if walls are not completely vertical there is 15mm of adjustment within the Wall Profile). **Note:** It is recommended that the walls are tiled after the Bath is fitted and grouted before fitting the Bath Screen. This will help provide maximum adjustment and will aid sealing.
- 1 No attempt should be made to rework toughened safety glass.
- 1 Pictures used are for illustration purposes only; product designs may alter slightly as a result of continuing product development.
- 1 The Curved Screen is designed for a shower head to be positioned **only** at the end of the bath - ensuring the spray is aimed down the full length of the bath at all times.
- 1 Our over-bath products are not designed for use with Baths featuring a shaped/stepped front or integral soap dishes.
- 1 The Extended Curved Bath Screen is suitable for use with powerful showering systems (non-pumped).

Component Check List: Supplied

Ref	Description	Quantities
A	Wall Profile	1
B	Fixed Panel	1
C	Curved Screen	1
D	Infill Trim	1
Fitting Pack 1		
E	3mm Drill Bit	1
F	40mm Screws	4
G	16mm Screws	3
H	Wall Plugs (for brick and block only)	4
I	Allen Key	1
J	Curved Screen Bottom Seal	1
K	Panel Bottom Seal	1
Fitting Pack 2		
L	Branding Badge (where applicable)	
M	Brace Bar	1

Equipment Checklist: Not Supplied

Electric Drill
6mm Masonry Drill Bit
Bathroom Sealant Gun
Bathroom Sealant Tube
Screwdriver
Spirit Level
Tape Measure
Pencil
Wall Plugs (Plasterboard)

Before Assembly and Installation of the Extended Curved Bath Screen

- 1 Check to see that you have the correct Bath Screen for your Bath. This can be done by referring to the label on the side of the product packaging.
- 1 Ensure all parts are in the packaging by checking them against the parts and quantities shown on the component check list above.
- 1 Check the product for defects. Installation queries on damaged parts can not be resolved once the installation has been completed.
- 1 The Bath must be completely sealed along tiled walls, fitted level (check with a Spirit Level) and should have no leaks.

Notes: It is recommended that the Wall Profile be fitted directly onto tiles or a similar sealed surface. If walls or Bath or a combination of both are out of level you will not achieve full adjustment of maximum width. We do not stipulate where the British Standard Safety Kite Mark should be positioned on the glass panels when being factory assembled.




Figure A

1. Ensure the Bath is completely level - check for any movement in the Bath by standing in it. Fill the Bath with water to check all plumbing for leaks.

Note: Please ensure the Bath is installed as per Manufacturer's Instructions.



Figure B

2. Fill the Bath with water and fully seal the Bath along the tiled walls with a bathroom sealant (not supplied). Once the Bath is fully sealed you must leave IT for at least 24 hours prior to commencing installation of the Extended Curved Bath Screen.

Note: Prior to commencing installation of the Bath Screen and once the sealant has cured, spray the shower handset around all joints to check for leaks.

Extended Curved Bath Screen Installation Procedure




Figure a1

1. Fit the inner edge of the Wall Profile (A) 5mm in from the inside edge of the bath (**Figure a1**). Ensure the Wall Profile is completely vertical using a Spirit Level. Mark the holes with a pencil where the Wall Profile is to be positioned.



Figure a1i




Figure a2

2. Drill the wall with a 6mm Masonry Drill Bit (not supplied) where the Wall Profile (A) is to be positioned. Fit the Wall Plugs (H) supplied (if going into a brick or block wall). If going into a plasterboard wall you will need to purchase appropriate wall fixings. Wipe clear all debris before referring to the next stage.




Figure a3



Figure a3i



Figure a3ii

3. Where the Wall Profile (A) is to be positioned onto the Bath, place a bead of Bathroom Sealant (not supplied) the width of the Wall Profile along the tiled wall (**Figure a3/a3i**). Screw fix the Wall Profile to the wall using the 40mm Screws (F). Ensure the Wall Profile stays completely vertical throughout this procedure using a Spirit Level (**Figure a3ii**).
Note: No Bathroom Sealant should be present between the Wall Profile and the tiled wall vertically prior to screw fixing.



Figure a4




Figure a4i

4. Seal the gap between the Bath and the Wall Profile (A) with a Bathroom Sealant (not supplied) (**Figure a4/a4i**).

Note: Failure to carryout this procedure correctly can result in serious water damage and is not covered by the 10-year manufacturer's Guarantee.




Figure a5



Figure a5i

5. Push the Panel Bottom Seal (K) onto the Fixed Panel (B) and cut to length (Figure a5) then slide the Fixed Panel over the Wall Profile (A) (Figure a5i).

Note: To complete the bottom seal installation please refer to step 17 at the end of the instructions. Failure to carryout this procedure can result in serious water damage and is not covered by the Guarantee.




Figure a6



Figure a6i

6. Remove the Top Swivel Moulding from the top of the Fixed Panel (B) by unloosening the screw with the Allen Key (I) supplied (Figure a6). Locate the Curved Screen (C) over the top of the Bottom Swivel Moulding on the Fixed Panel (Figure a6i) ensuring that both bath screen spacers are flat on highest point of the bath top.




Figure a7




Figure a7i

7. Once the Curved Screen (C) is pushed completely down onto the top of the Bottom Swivel Moulding as in Stage 6, fix the Top Swivel Moulding over the top of the Curved Screen and Fixed Panel (B) (Figure a7). With the Allen Key (I) supplied secure the Top Swivel Moulding (Figure a7i).




Figure a8



Figure a8i

8. Ensure the Fixed Panel (B) overlaps the Wall Profile (A) by at least 5mm (Figure a8). Inside the Bath, drill three holes through the Fixed Panel into the Wall Profile with the 2.5mm Drill Bit (E) supplied. The three holes should be drilled through the Fixed Panel in the pre-drilled holes into the Wall Profile. Ensure that the bath screen spacers remain level on the bath and 50mm from each end of the screen (Figure a8i) throughout this process.

Note: Before starting this procedure ensure your Bath is completely level otherwise further adjustment may be required at a later stage to enable your Curved Bath Screen to be parallel and sealed to the Bath top.



Figure a9

9. Screw fix the 16mm Self-tapping Screws (G) supplied into the holes drilled in Stage 8. Ensure that the Screws are fully tightened with a Screwdriver (Figure a9)




Figure a10




Figure a10i

10. Remove spacers and push the Curved Screen Bottom Seal (J) completely onto the Curved Bath Screen (C) (Figure a10). Ensure the deflector strip on the Bottom Seal faces inwards towards the Bath (Figure a10i). This will enable water to be deflected into your Bath whilst using the shower. Once the Bottom Seal is in place cut to length ensuring the seal does not exceed the length of the Curved Bath Screen.




Figure a11




Figure a11i



Figure a11ii

11. Using the full Bracing Bar assembly (M) position over the top of the glass of the Fixed Panel (B) (**Figure a11**). Ensure the Brace Bar is completely level and in line with the glass clamp that is over the top of the Fixed Panel (**Figure a11i**). Using a Pencil, mark on the wall the position where the bracket which is already fitted at the end of the Brace Bar touches the wall (**Figure a11ii**).



Figure a12



Figure a12i




Figure a12ii

12. Using the Allen Key which is supplied with the Bracing Bar (M) loosen the grub screws at the top and bottom until the brass locating nut in the end of the bracket can be removed (**Figure a12**). Take the brass locating nut out of the bracket, place the brass locating nut where the Brace Bar is to be positioned, using a Pencil, mark through the hole of the brass locating nut (**Figure a12i**), drill the hole for the brass locating nut using a 6mm Masonry Drill Bit (not supplied) (**Figure a12ii**). Insert the Wall Plug (H) (if going into a brick or block wall). Using a Screwdriver screw fix the brass locating nut with the 40mm Screw (F).




Figure a13



Figure a13i

13. Position the Brace Bar (M) over the top of the glass of the Fixed Panel (B) and then over the top of the brass locating nut which was screw fixed in Stage 12 (**Figure 13**). Using the Allen Key tighten the grub screws at the top and bottom of the bracket (**Figure a13i**).

Note: Do not over tighten grub screws.




Figure a14

14. Slide the spacers in-between the glass and the Brace Bar glass clamp - this will ensure that no aluminium touches the glass of the Fixed Panel (B). Using a Screwdriver tighten the screw shown in (**Figure a14**).



Figure a15

15. The length of the Bracing Bar (M) can be adjusted by loosening the two grub screws at the top of the bracket using the Allen key (**Figure a15**).

Note: Do not over tighten grub screws.



Figure a16



Figure a16i




Figure a16ii

16. Once satisfied with the installation of your Extended Curved Bath Screen, seal both sides of the Wall Profile (A) inside and outside only where it meets the tiles. Fully seal the base of the Fixed Panel (B) along the Bath top from the outside only (**Figure a16i/a16ii**).

Note: Please allow at least 24 hours for the sealant to cure prior to using your Extended Curved Bath Screen. Once the sealant has cured press fit the Infill Trim (D) into the groove of the Fixed Panel (B) to conceal the 16mm screws (G) (**Figure a16**).




Figure a15

17. To complete the sealing of the enclosure the fixed panel bottom seal must be sealed to the outside of the bath. The black line on **Figure a17** indicates where you must place sealant.

18. Ensure the Branding Badge (L) (where applicable) is placed prominently on a non moving aluminium part.

Should you experience any problems during installation please refer to the Trouble Shooting Guide or contact Customer Relations on:

+44 (0) 1325 328033/328034

To enable customer relations to provide you with an excellent level of service it is important that you quote your Product Code and Reference Number - these numbers can be found on the guarantee card.

Trouble Shooter Guide

Problem		Solution
Leaking	①	Check that the internal joint between the Bath and the Wall Profile has been sealed correctly (Figure a4/a4i).
	②	Ensure that the Bath is fully sealed along the tiled walls prior to installation (Figure B).
	③	If the internal joint between Fixed Panel and Bath is sealed, this will cause leakage – the sealant must be removed.
	④	Ensure that the Wall Profile on the tiled wall is sealed both internally and externally (Figure a16i/a16ii).
	⑤	Ensure the external joint between the Bath Screen and the Fixed Panel is fully sealed.
	⑥	Is the Wall Profile fitted to the inside edge of the Bath (Figure a1/a1i)?
Bath Screen alignment on Bath	①	Is the Bath Screen fitted onto a tiled wall?
	②	Is the Wall Profile fitted to the inside edge of the Bath (Figure a1 / a1i)?
	③	Is the Wall Profile completely vertical?

Some important information to help you Maintain your product.

The following information is all you need to keep your product looking new.

Clean your product using a mild detergent diluted in water and then polished off using a soft cloth.

If you live in a hard water area, periodically clean your product using a 50/50 solution of white vinegar and water. The solution should be left on the enclosure for approximately 5 minutes then rinsed off using warm water. This method of cleaning should remove lime scale residue.

Simple maintenance.

Our products are generally maintenance free, however it may be necessary to lubricate wheel assemblies and other moving parts from time to time.

It is strongly recommended that a quality silicone spray is used.

A list of Don'ts:

- 1 - Don't use acidic based products which are unsuitable for cleaning enamel surfaces.
- 2 - Don't use Abrasive cleaners or cleaners containing bleach or solvents, these products will adversely affect the finish of the aluminium profiles.
- 3 - Don't use scouring pads, powder or any sharp instruments when cleaning the enclosure.