

Care Instructions

Shower enclosures should be cleaned after every use. To prevent limescale from building up, use a squeegee, a soft cloth or chamois leather - but no cleaning agent - to wipe off any water droplets left after showering. Residue left by bodycare products (liquid soap, shampoo, shower gel) can also cause substances to accumulate. Use water to rinse away residues after use. All sliding door track fittings should also be cleaned this way - to ensure that they continue to run smoothly.


- Don't allow limescale to build up - especially in hard water areas
- If you do get a stubborn limescale build up, a mixture of 50:50 vinegar and water will help you to clean it away - but make sure all vinegar is rinsed off completely
- Never use strong detergents or cleaning agents
- Cleaning materials should wherever possible be rated between PH4 and PH8
- In no circumstances should you use any abrasive substances

Registered office: Lawton Road, Alsager, Stoke-on-Trent, ST7 2DF, UK
T: +44(0) 1270 879777 F: +44(0) 1270 870087
E: shower.team@twyfordbathrooms.com
www.twyfordbathrooms.com
Part of the Sanitec Group

OUTFIT

by Twyford


Bi-Fold Door with or without Side Panel



Twyford
showering

IMPORTANT

Please read carefully the following instructions before installing your shower enclosure to ensure safe and proper use and avoid any injury to either the installer or user. Failure to comply may invalidate your guarantee.



Bi-Fold Door Components list			Fixings Pack		
Part No:	Description	Qty	Part No:	Description	Qty
1	Wall Vertical profile	2		Allen Key	2
2	Inner Vertical profile	2		Pan hd self-tapping screw 10mm lng	8
3	Top and Bottom rail	2		Pan hd self-tapping screw 10mm lng	16
4	Two part hinged glass door	1		Hinge block screws 20mm lng	4
5	Bottom door seal	2		Plastic wall plugs	8
6	Hinge block	2		Drill bit dia 3.2mm	1
7	Roller Hinge assembly	2	12	Chrome hinge screw cover caps	4
8	Magnetic Door Seal	2	13	Hinge screw cover caps	4
9	Handle	1	14	Roller hinge block ctr screw cvr cap	2
10	Screw cover strip	2		Hinge block csk Hex drive bolts	4
11	2 piece cover caps	2	15	Magnetic strip end stops	2

Side Panel Components list			Side Panel Fixings Pack		
Part No:	Description	Qty	Part No:	Description	Qty
1	Glazed Panel & Corner Post	1		Pan hd self tapping screw 10mm lng	4
2	Towel Rail	1			
3	2 piece cover caps (LH/RH)	2			
4	Screw cover strip	1			

side panel items not pictured

prior to installation:


Before Installing the shower screen, install the shower tray as per the manufacturers instructions making sure that tray is level in all directions.

We recommend that the tray is installed before tiling down onto the tray.

step 1. installation in an alcove


Position the wall profiles approx 12mm in from the edge of the tray or inside of up-stand

For installation with a side panel please see step 17




step 2.

Make sure both wall profiles are upright using a spirit level.




step 3.

Mark the position on the wall through the pre drilled holes with your pencil. Carefully move the wall profile away from the wall and put somewhere safely to avoid damage when you start drilling.



step 4.


Drill holes where marked using the 6mm masonry drill bit. (You may need a specialized drill bit if you are drilling into tiles, if unsure please get advice). You can now install the wall plugs that have been provided.




step 5.

Screw one wall profile to the wall making sure you keep the profile vertical. Use the 30mm screws provided.


For Alcove repeat steps 2-4 for the second profile, but **DO NOT** screw to the wall at this stage. **Then continue to step 6.**
For Corner installation **go to step 8.**






step 6.

Loosely locate the unfixed wall profile into the vertical door profile, as shown **A**. Then, slide the whole unit into the fixed wall profile, **B**.





loose profile shown here.




step 7.

Pivot the whole assembly around the fixed profile to it's final position. By parting the loose profiles, indicated below, the other wall profile can be screwed into your pre-drilled holes.




step 8.

Ensuring the screen is central between the walls and vertical, drill through the pre-drilled holes in the shower profile into the wall profile using a 3.2mm diameter drill. Secure together using the 10mm screws provided. Once tight install the screw cover strip.




**For installation in an alcove continue to 9.
For installation in a corner go to step 18.**




step 9.

Fit the profile cover caps as shown.




step 10.

Fit the profile cover caps as shown. Then apply the badges as indicated.




step 11.

Slide on the bottom door seals. Ensure the drip bar points towards the inside of the enclosure.




step 12.

Insert the plastic end-stop into the 'T' shape slot located at the bottom of the door **A**. Then check the polarity of the magnetic door strip against the one located in the shower screen itself. When you are happy it is the correct way round slide the magnetic strip down the same 'T' slot **B**. Make sure it reaches the end-stop.




step 13.

Install the handle as shown.




step 14.

Using an allen key, adjust the fixed hinges left or right to obtain flush door seals. The moving hinge block also has adjustment.



step 15.

Install the cover caps, as shown, to all hinges.



step 16.

Using good quality clear silicon sealant, seal the enclosure to the wall and tray along the following joints:


A: Outside vertical enclosure-to-wall joint.

B: Inside vertical enclosure-to-wall joint.

C: Outside Perimeter enclosure-to-tray joint.

D: 150mm high wall profile-to-enclosure joint.


(Make sure side panel is sealed in the same way, if installed)



step 17. Installation in a corner.



Position left and right wall profiles as shown in the diagram.

Once complete, continue with steps 2-5




step 18.

Ensuring the side panel is vertical, drill through the pre-drilled holes in the shower profile into the wall profile using a 3.2mm diameter drill. Secure together using the 10mm screws provided. Once tight install the screw cover strip.



step 19.

At the corner posts. Drill through the pre-drilled holes in the screen profile into the side panel profile with the 3.2mm drill bit provided. Secure with the 10mm screws provided. Then, install the screw cover strip and the profile cover caps provided. See step 12 for additional diagrams.



step 20.

Install the Towel Rail onto the external face of the side panel, as shown.

Once complete, continue with steps 9-16